


Spot for Blackberry User Manual

Skylab's positioning and orientation tool



Version 1.4.1

Contents

1	Introduction	3
2	Installation	4
2.1	Devices	4
2.2	Installation - over the air (OTA)	5
2.3	Registration	6
3	Using Spot	8
3.1	Settings	8
3.1.1	Launching	8
3.1.2	Location Provider	8
3.1.3	Global Settings	10
3.1.4	Key Configuration	12
3.1.5	Hardware Info	12
3.1.6	Log	12
3.2	Position Info	13
3.3	Map	13
3.3.1	Navigation in Map View	14
3.3.2	The Layer Manager	17
3.3.3	Web Map Service	17
3.3.4	Waypoints Layer	18
3.3.5	Tracklog Layer	18
3.3.6	Worldmap Layer	19
3.4	Waypoints	19
3.4.1	Add Waypoint	20
3.4.2	Browse Waypoints	20



3.4.3	Manage Categories	22
3.4.4	Get Geocaching Details for Waypoints	22
3.4.5	Waypoint Import and Export	22
3.5	Elevation	23
3.6	Satellites	23
4	Troubleshooting	24
4.1	FAQ	24
4.2	Customer Support	25
5	Warranty	26
5.1	License	26
5.2	WMS Usage	26
5.3	Using Spot while Driving a Vehicle	26
5.4	Third Party Announcements	26

1 Introduction

Spot combines the power of GPS with worldwide maps and a flexible waypoint management. Orientation and routing enables you to find interesting places, store and share them with others.

Spot's features:

- Positioning information: GPS status, coordinates, height, speed, heading, signal strength and current time
- Maps: Integrated world map, map download from the Internet or import of your own maps, simultaneously display waypoint and map layers
- Waypoint management: Add, edit, categorize, import and export waypoints
- Satellites: Get the position information of satellites in view (only available when using Bluetooth GPS)
- Elevation: Elevation graph of your track

Spot contains plenty of features for freetime and professional users. Using modern Java technology allows us to offer *Spot* for many more platforms than just the Blackberry. It is able to run on nearly any Java-enabled mobile device. Most of the current mobile phones and PDAs (running PalmOS or Windows) are compatible to the normal *Spot* version. You are not limited to the Blackberry platform (please note: the non-Blackberry version does not run on Blackberry devices and vice versa). The custom WMS server feature allows to integrate *Spot* into an existing (OGC WMS compatible) company GIS (Geographic Information System) plus the usage of free accessible WMS servers on the Internet. Furthermore there are some features like field navigation, statistics (track elevation, tracklog, etc.), waypoint/POI/landmark management, full screen maps, satellite maps, moving map navigation and others.

2 Installation

2.1 Devices

This version of *Spot for Blackberry* runs on Blackberry 7520 and 7100i using its built-in GPS receiver.

Using *Spot for Blackberry* on other Blackberry devices (e.g. 7100, 8700 Series and 7250, 7290) requires an external Bluetooth GPS receiver.



Figure 2.1: General Blackberry Controls

2.2 Installation - over the air (OTA)

Spot can be downloaded OTA via Internet to the device and installed directly. This is the easiest method to install *Spot* on your device. The Blackberry needs a working Internet connection. You can use the WAP browser or the Blackberry browser to access Skylab Mobilesystems' OTA Download Center and install it directly.

The OTA download link for the most recent demo version of *Spot* is located at:

<http://micro.skylab-mobilesystems.com/>



Figure 2.2: Downloading *Spot for Blackberry*

Be sure to choose the right link. *Spot for Blackberry* is located under the corresponding title and the link is called `spot.jad`.

2.3 Registration

Spot for Blackberry comes by default as a fully functional demo version with a runtime limitation. To check whether you have a demo or full version installed use the *About* screen.

If the installation is a demo version it will display: *Not registered!*



Figure 2.3: About screen of a demo version



If it is a registered version it will show: *Registered to: YOUR NAME*




Figure 2.4: About screen with registration information

To register your demo version of *Spot* for Blackberry click *Register Spot* for Blackberry in the main menu and enter your name and serial number you have received from Skylab Mobilesystems or one of our distributors.

Handango: Please enter your **RIM Esn / PIN** in the name field and the **license key** in the serial field.

Share-it: Please enter your **registration name** in the name field and the **license key** in the serial field.

3 Using Spot

3.1 Settings

3.1.1 Launching

To launch *Spot* for Blackberry on your Blackberry highlight the green *Spot* icon on the Blackberry home screen and press the Trackwheel.



Figure 3.1: The *Spot*

3.1.2 Location Provider

The *Location Provider* is an important part of *Spot*. This component provides the positioning function for all position based features. A location provider must be activated for the positioning support to work.

On Blackberry 7520 and 7100i

The Blackberry has a nicely implemented integrated GPS module. *Spot* for Blackberry activates the associated location provider automatically and does not need any user



interaction.

Your Blackberry may restrict access to the GPS location data. The access provided to the built-in GPS receiver can be one of the following three:

1. Restricted - GPS data delivery is blocked
2. Unrestricted - all applications can access GPS data
3. By Permission - the user will be asked whether an application should be granted access to GPS data or not

To configure the access restriction setting select **Options**→**Location Based Services** from the Blackberry main screen and use **Change Option** to change the privacy access control to **Unrestricted** or **By Permission**.




Figure 3.2: Setting up **Location Based Services**

Note: The default setting is By Permission.

On 7100, 8100, 8700 Series and 7250, 7290 Blackberry devices in combination with a Bluetooth GPS receiver

All Blackberry devices with Bluetooth support can be configured to use *Spot* with a Bluetooth GPS receiver. Even though you might be able to change some settings under **Options**→**Location Based Services** that does not necessarily mean your device has a built-in NAVSTAR satellite GPS receiver. You might need an external one to use *Spot*'s positioning features.



Pair two Bluetooth devices

1. Select Options→Bluetooth
2. Press the Trackwheel
3. Select Add Device
4. Select the name of the appropriate device you want to use
5. Authenticate yourself to the device by entering the **passkey** for the Bluetooth device
6. Enter the same **passkey** on the Bluetooth device

Connect Spot to your Bluetooth GPS receiver *Spot* automatically connects to the first Serial Port Profile (SPP Slave) device on startup. On startup you will be informed by a popup whether the connection was successful. Usually you do not need to do anything else for the positioning to work. If you want to change the Bluetooth GPS receiver during runtime go to Settings→Bluetooth GPS, press the Trackwheel and select Stop BT GPS. Now select the device in the list you want to connect to, press the Trackwheel again and choose Select. A connection information screen will appear showing whether the connection could be established successfully or any error has been occurred.

3.1.3 Global Settings

You can modify the following global settings:

Center Map to Location Automatically centers the map to the current position as reported by your location provider.



Show Position on Map Shows the latitude/longitude of the current position on the map screen.





Power Saving Mode Activating this option will lessen *Spot*'s usage of the positioning device and should decrease battery drain. As a disadvantage positioning information will be less accurate and updates will be slower.



Units You can choose between metric and imperial (also known as US customary or English) unit representation.



Time You can choose between local time and General Mean Time / Universal Time Coordinated (GMT/UTC) display.



Draw Text Background If this option is enabled text outputs (position, button action) in the map view will be painted on a solid background for better readability.



Check on Startup for New Version If this option is enabled *Spot* for Blackberry will automatically check on startup whether you are using the latest version (recommended).





Overwrite Network Defaults If this option is enabled the default network settings of your device are overridden and you are able to choose between **Direct TCP (Non-BES-Mode)** and **Proxy TCP (BES-Mode)**. If you are using a **Blackberry Enterprise Server (BES)** you should select **Proxy TCP (BES-Mode)** if the default setting does not work for you.



The default network setting when **Overwrite Network Defaults** is disabled depends on the network you are using. Here is an overview:

Network	Default network setting	Alternate network setting
GSM	Proxy TCP (Non-BES-Mode)	Direct TCP (BES-Mode)
iDEN	Direct TCP (BES-Mode)	Proxy TCP (Non-BES-Mode)

Table 3.1: Default network settings according to the network

The settings are saved on your mobile device and are reloaded on the next start of the application.

3.1.4 Key Configuration

Spot supports a wide range of devices which often have different key layouts. If the default binding does not work or is not comfortable for you, you can change it here. You have to press a key for each function and select "next key" from the menu until all keys are set.

3.1.5 Hardware Info

Shows device specific information like CLDC and MIDP versions and JSR capabilities.

3.1.6 Log

The application's log file for information and debugging purposes.



3.2 Position Info

The Position Info screen shows the current position according to your location provider, e.g. your GPS receiver. Apart from the GPS status indicator it displays longitude and latitude in decimal degrees, height, speed and time information. A typical Position Info screen looks like this:




Figure 3.3: Position information

3.3 Map

The Map view shows your current position on data layers.

Spot supports the following data layers:

- OGC Web Map Services (WMS)
- Waypoints / Points Of Interest
- Tracklog
- Worldmap



3.3.1 Navigation in Map View




Figure 3.4: Items on the map

You can navigate in the map view by pressing the corresponding keys to zoom and pan or let the location provider automatically pan to the current position. The default key layout for navigation in the map depends on the device you are using:

▲ UP: used for panning north and zooming in

▼ DOWN: Used for panning south and zooming out

◀ LEFT: Used for panning west

▶ RIGHT: Used for panning east

● SWITCH: Used for switching between pan and zoom mode

zoom factor ZOOM FACTOR: Used to change the zoom factor (2x, 4x, 8x)



Action	7200, 7500, 8700 series	7100 series
	2/E	2/TY
	8/X	8/BN
	4/S	4/DF
	6/F	6/JK
	5/D	5/GH
zoom factor	Space	0/Space

Table 3.2: Key mapping device matrix



Figure 3.5: Default Key Settings on 7200, 7500 and 8700 Series



Figure 3.6: Default Key Settings on 7100 Series

You can set up your own key layout in **Settings**→**Key Config**

If you activate the "center map to location" feature the **pan**-mode is replaced by **auto center**. Panning is done automatically depending on your position. To avoid a too frequent recentering of the map, which might result in new Web Map Service requests if you have enabled a WMS layer, the map is only recentered if the current position differs more than 20 pixels from the display center. This feature can be set through:

Settings→**Global Settings**→**center map to location**

or

Map→**Global Settings**→**center map to location**.

In **zoom** mode there are 3 different zoom levels: 2x, 4x and 8x. You can switch between the zoom levels with the **1**-key or the key you have configured in your settings. It is also possible to select "zoom in" and "zoom out" from the Trackwheel menu.



3.3.2 The Layer Manager




Figure 3.7: Layer manager screen

To add new layers or to toggle the visibility of layers use the "Layer manager" in the menu. The Layer manager shows a list of all currently loaded layers and their visibility setting which can either be visible (checkbox is checked) or invisible (checkbox is not checked).

Scale info is a special layer which shows the current scale in the lower left corner of the map.

3.3.3 Web Map Service




Figure 3.8: WMS Layer Options



Due to compliance to the OGC (Open GIS Consortium) WMS standard you can access a huge amount of free Web Map Services which provide you with topographic, aerial and street maps directly to your Blackberry device. You are not bound to a subscription based service or restricted to use a specific proprietary map service. Skylab Mobilesystems hosts a list of public accessible WMS services at http://www.skylab-mobilesystems.com/en/wms_serverlist.html. Each WMS usually allows you to select multiple layers which are rendered into one image by the server. Spot has integrated some example WMS URLs. To change the default WMS select: **LayerManager**→**Web Map Service**→**Options**. You can use a custom WMS by entering the Capabilities URL.

3.3.4 Waypoints Layer

The waypoint layer shows all saved waypoints on the map. Each waypoint is visualized with the corresponding waypoint category icon or a red rectangle if no icon has been selected. All waypoints are labeled with their name if it fits on the map screen without colliding with other labels. If you can't see the labeling, it is most likely that there are several waypoints clustered together. Zoom in to reduce the amount of visualized waypoints.

3.3.5 Tracklog Layer




Figure 3.9: A sample tracklog layer

The tracklog layer visualizes your track on the map.



3.3.6 Worldmap Layer




Figure 3.10: The default worldmap layer

The worldmap layer displays a rough map of the world for a quick orientation. If you need a more detailed map you might want to add a Web Map Service layer or a map image layer.

3.4 Waypoints




Figure 3.11: A sample waypoint layer

The waypoint menu allows you to manage your waypoints. You can add, browse, import and export waypoints or use the routing feature.



3.4.1 Add Waypoint

This option allows you to create a new waypoint. If the location provider delivers a position, the latitude, longitude, and height field will be pre-filled with data from the current position. You can change them if you like to. If no position is available the fields default to "0". The following information can be entered:

- X: the longitude in decimal degrees
- Y: the latitude in decimal degrees
- Z: the elevation in meters or in feet (go to **Settings**→**Global Settings**→**Units** to change the unit settings)
- Category: select on of the preconfigured or your own categories to sort your waypoints
- Name: a short name for the waypoint, limited to 20 characters
- Description: description of or additional information for the waypoint, limited to 200 characters

3.4.2 Browse Waypoints




Figure 3.12: Browse Waypoints screen



You can browse through all waypoints stored on your device. Each waypoint is displayed in the list with the waypoint name and its corresponding category symbol. You can perform the following operations on the selected waypoint: **Edit**, **Delete**, (show) **Details**.

Details: Shows all available information for the selected waypoint.

Edit: You can edit all fields of the waypoint like in Waypoints→add Waypoint.

Delete: Deletes the selected waypoint.

Route To: Route to an existing waypoint from your current location. To allow the routing to a waypoint, select one in the list and activate the routing screen by pressing **select**. If you have not created or imported waypoints before, the list will be empty. The routing screen will show you a blue arrow that tells the direction you should go towards your target destination. Furthermore it shows information like the waypoint's name, your current speed, the estimated time of arrival (ETA) and the estimated time en-route (ETE). The circle around the direction arrow is a compass. The red line of the circle shows the north direction based on the GPS heading.




Figure 3.13: Going to Joey

Note: If you are not moving some GPS receivers will report a speed of 0 km/h or mph and a heading of 0 degrees. This will show a direction heading north. Furthermore ETA and ETE cannot be calculated if you are not moving.



3.4.3 Manage Categories

You can manage your waypoint categories here. Each waypoint belongs to one category. If no category is specified, the waypoint is associated with the default category. You can **add**, **rename** or **delete** a category, or change its **icon**.

Add: Creates a new waypoint category.

Select Icon: Chooses an icon for the category. This allows you to quickly identify the category of a waypoint on the map.

Rename: Renames an existing category.

Delete: Deletes the selected category. If the category contains waypoints, you can choose to move them to the default category or delete them as well.

3.4.4 Get Geocaching Details for Waypoints

Spot has extensive built-in geocaching support. For geocaches from <http://www.geocaching.com> the cache description can be downloaded on the fly. After downloading the cache description it will be added to the waypoint description. Use **Waypoints**→**Browse Waypoints**→**Details**→**Get cache description** to download it.

3.4.5 Waypoint Import and Export

You can import waypoints in the popular waypoint formats GPX and LOC. Details on other applications supporting GPX and sites with GPX waypoints can be found at <http://www.topografix.com/gpx.asp>.

To import waypoints from a website select **Waypoints**→**GPX import (web)** or select **Waypoints**→**LOC import (web)**. The waypoints will be downloaded to your device and integrated into the *Spot* waypoint database. The waypoints will be stored in a new category named after the download URL.

Note: These options only appear if JSR-75 is supported.



3.5 Elevation

The elevation screen shows the track elevation from the currently recorded tracklog (the tracklog itself can be made visible in the map view). There are two labels in this screen to show the relation of the elevation. The top label indicates the highest elevation the user has reached during the current track. The lower label indicates the average elevation of the track. The bottom represents the lowest altitude the user has been on during track recording. A common Elevation screen may look like in the following image:




Figure 3.14: Tracklog Elevation Visualization

3.6 Satellites

Note: This screen is only available on devices which do NOT have a built-in GPS receiver and are used with an external Bluetooth GPS receiver!

The satellite screen is a passive component. It shows the current positions of satellites in view and their signal strength. The closer a displayed satellite is to the outer circle the closer is the satellite's position to the horizon. The closer it is shown to the center of the circle the more it is moving to the zenith above you. The inner circle symbolizes positions in an angle of 45° between the horizon and the zenith. The bars show you the signal strength of a single satellite.

4 Troubleshooting

4.1 FAQ

Why do I get the error message "net_rim_locationapi not found" on my Blackberry 7520?

Some old versions of the Blackberry 7520 do not have the location API installed by default. A software update on your Blackberry will add it. Use the following link to download and update your Blackberry software:

<https://www.blackberry.com/SoftwareDownload/index.jsp?client=biTZdMddN>

Where is the Satellite info view?

Spot has a view which provides additional information about the GPS satellites. We removed this view from the Blackberry version of Spot, because the Blackberry does not provide this information which makes the view useless.

I can't install Spot with the Application Manager. What's wrong?

Currently you have to install Spot via OTA. You can download Spot directly to your device by using our OTA website in your Blackberry browser:

<http://micro.skylab-mobilesystems.com>

I get a map of the world, but I do not know where I am, what's wrong?

The map screen shows the worldmap as default map if no GPS position has been received. After the first GPS position is received, *Spot* will automatically zoom to your current position.



I can't see a map and got a "WMS ERROR", what's wrong?

A WMS Error indicates a problem with the Mapping Service which is currently in use. It might be a problem with your internet connection or a problem of the map server. You can check the error details in **Settings**→**Log**. If you cannot figure out what is wrong please send us an e-mail with the error description.

Why does Spot drain the battery off that fast?

Earlier beta versions of Spot had a problem with power consumption on the Blackberry. The current version should work much better. You can select a power saving mode (**Settings**→**Global Settings**→**Power saving mode**) which will improve the battery time but may result in slower/less accurate GPS positions.

Spot exits after some minutes. Why?

Spot is generally distributed as a demo version and will exit if the time limitation is reached. In this case, a message will be shown that the time limitation of the demo version is reached and *Spot* will exit. If you are not actively using *Spot* at that moment you might miss this user information alert. However you can restart *Spot* again and if you have received a serial key from Skylab Mobilesystems Ltd. or one of our distributors you should enter it in Spot to enable the full version which does not have a runtime limitation.

4.2 Customer Support

Please send us an email with your questions or comments. We monitor all emails and will promptly reply to your inquiries.

Email: info@skylab-mobilesystems.com

5 Warranty

5.1 License

Copyright by Skylab Mobilesystems 2005, 2006, all rights reserved. *Spot* is subject to the Skylab Mobilesystems Ltd. Software License Agreement which version is available from <http://www.skylab-mobilesystems.com/en/license.txt>.

5.2 WMS Usage

The contained Web Map Server configuration for the map screen is an example configuration. There are no relations between Skylab Mobilesystems Ltd. and the respective service providers. Furthermore this configuration shall only show how free accessible WMS services can be used with *Spot*. They are NOT part of *Spot*.

5.3 Using Spot while Driving a Vehicle

Keep your eyes on the street! If you are using *Spot* in a vehicle while driving keep your eyes on the street. It is commonly known that distracted drivers cause more accidents than attentively ones. In some countries it is forbidden to use mobile devices while driving.

5.4 Third Party Announcements

All rights of all announced trademarks, registered trademarks, products, images and symbols belong to their corresponding company.