

How to upgrade TP-LINK Range Extender

Notice:


- **Please verify the hardware version of your device for the firmware version. Wrong firmware upgrading may damage your device and void the warranty.**



TL-WA730RE V2 130510 ↓	Published Date	2013/5/10
	Language	English
	File Size	3.46 MB
	Operating System	Win2000/XP/2003/Vista/7/8/Mac/Linux
	Modifications and Bug Fixes	<ol style="list-style-type: none">1. Fixed an ARP broadcast storm problem caused by IP conflict;2. Fixed a compatible problem in Thailand;3. Fixed a bug that wireless may encounter disconnection when there are over 8 clients with powersave enabled;4. Fixed some vulnerabilities and improved security.
Notes	For TL-WA730RE V2	

- **After you downloaded the firmware from TP-LINK website, please use decompression software such as WinZIP or WinRAR to extract the firmware file to a folder;**
- **Do NOT upgrade the firmware via wireless connection unless the device only has wireless connection;**
- **Do NOT turn off the power or cut down the Ethernet cable during upgrade process;**
- **Please write down all the settings which you changed from the default values, since you may need to reenter them manually.**

Step 1 Log into the TP-LINK device by typing <http://tplinkrepeater.net/> in the address bar of the web browser (such as Internet Explorer). The username and password are both **admin** unless you have changed it before.



Step 2 Click **System Tools** ->**Firmware Upgrade**, click the **Browse** button to choose the firmware you already extracted in the folder.

Firmware Upgrade

New Firmware File:

Browse

Firmware Version:

1.0.0 Build 20150611 Rel. 60542

Hardware Version:

RE450 v1.0

Upgrade

Step 3 Click the **Upgrade** button. The device will reboot automatically after the upgrading has been finished. Please wait about 3 minutes.

A screenshot of the TP-LINK Range Extender web interface. The left sidebar shows a menu with 'Status' highlighted. The main content area displays a network diagram with 'Internet', 'Router', 'Range Extender', and 'Clients' connected. Below the diagram is a 'Range Extender' configuration table. At the bottom, the 'Firmware Version' and 'Hardware Version' are displayed.

Extended 2.4GHz		Extended 5GHz	
SSID:	TP-LINK_Extender_2.4GHz	SSID:	TP-LINK_Extender_5GHz
Channel:	11	Channel:	36
MAC Address:	00-0A-EB-13-7B-00	MAC Address:	00-0A-EB-13-7B-02

Wired

DHCP Server: Auto (Off)

IP Address: 192.168.0.100

Type: Dynamic IP

Firmware Version: 1.0.0 Build 20150611 Rel. 60542 Hardware Version: RE450 v1.0 Support

Step 4 Click **Status**, verify that the device's firmware has been upgraded.

Step 5 Then, check the status page of your device, if necessary please re-enter or reconfigure the device manually with the parameters you have written down before upgrading.